

PSEUDO CODE FOR STM32 NUCLEO

```
// Initialization Method for Precision Dispensing System
// Initialize components
FUNCTION Initialize_System():

    // Set up peristaltic pump
    Configure Pump to Default State // Ensure the pump is off initially
    Set Pump Direction to Forward using relay circuit // Prepare for initialising using Relay for
    polarity switching such that the direction of flow for forward dispensing

    // Configure load cell and amplifier (HX711)
    Initialize Load_Cell // Power on the load cell
    Calibrate Load_Cell with HX711 // Perform calibration to zero out initial weight
    Set Load_Cell_Thresholds (Red_Solution_Target, Blue_Solution_Target) // Define target
    weights for solutions
    Tare Load_Cell // Set initial weight as zero for accurate dispensing

    // Initialize display
    Initialize OLED_Display // Set up I2C communication for OLED

    // Set up servo-driven pinch valves
    Set Servo_Pinch1 // pinch valve for red solution
    Set Servo_Pinch2 // pinch valve for blue solution

    // Configure servo motor for outlet switching
    Initialize Servo motor // Set up the motor for outlet switching
    Set servo to either of the containers // Position at the starting location for dispensing

    // Configure cycle and delay timing variables
    Set Cycle_Count to 0 // Initialize cycle count to track dispensing cycles
    Set Reverse_Pump_Delay to 30-40 seconds // Set time delay for reversing the pump
    after dispensing

END FUNCTION

// Start process loop for 5 cycles

FOR cycle = 1 TO 5 DO

    // Dispense red solution
    Activate Servo_Pinch1 // Open pinch valve for red solution
    Select Outlet1 // Direct output to container for red solution
    Start Pump // Begin dispensing using Relay for polarity switching such that the direction
    of flow changes

    // Continuously read load sensor and update display
```

```
WHILE Load_Cell_Reading < Red_Solution_Target DO
  Display Load_Cell_Reading on OLED
END WHILE
```

```
Stop Pump // As the target weight for red solution reached.
Reverse Pump // Move any residual solution back to red reservoir using relay module to
change the polarity of pump
Delay 30-40 seconds // Allow time for residual solution to clear
```

```
Deactivate Servo_Pinch1 // Close pinch valve for red solution
```

```
// Dispense blue solution
Activate Servo_Pinch2 // Open pinch valve for blue solution
Select Outlet2 // Direct output to container for blue solution
Start Pump // Begin dispensing
```

```
// Continuously read load sensor and update display
WHILE Load_Cell_Reading < Blue_Solution_Target DO
  Display Load_Cell_Reading on OLED
END WHILE
```

```
Stop Pump // Target weight for blue solution reached
Reverse Pump // Move any residual solution back to blue reservoir
Delay 30-40 seconds // Allow time for residual solution to clear
```

```
Deactivate Servo_Pinch2 // Close pinch valve for blue solution
```

```
END FOR
```

```
// End of cycle loop
```